

# STS Load Station

### STS Pre-Preparation System



#### SAFE AND ACCURATE PRE-FILLING

When processing half-tablets, rarely used medicines or specially shaped tablets, the automated dispensing system with LEDs allows for safe and accurate pre-filling, while reducing filling time and preventing filling or dispensing errors. \* RFID function is optional.



# PRE-FILL CHECKING WITH LEDS

Individual LEDs for each cell help in dispensing the necessary tablets and indicate errors to ensure convenient and accurate filling. If medicines are wrongly dispensed, the LED colour changes to yellow to indicate the filling location in question.

\* Red: Not filled, Green: good filling, Yellow: wrong filling



#### FAST AND ACCURATE STS TABLET COLLECTION

The list of STS medicine details transmitted from the server can be printed to enable fast and accurate medicine picking from storage.



### EASY TO CLEAN(GMP COMPLIANT)

Each cell is detachable and easy to wash. The dust collector and suction opening at the bottom of the system also help to keep the environment and the system clean.



Model	JV-LS10*
Dimensions (WxDxH)	654 x 417 x 132mm
Weight	About 18,5kg
Detectable tablet size	Min.ø3x1mm
Display	Touchscreen monitor 50,8cm (20")/All-in-one PC
Power consumption	25W
Power supply	100-240V~, 50/60Hz

\* Product exterior and specifications are subject to change due to the company's research and development results without any prior notice \*\* All information contained herein may not be duplicated, copied, altered, or quoted without the expression written consent of JVM.



#### JVM Europe B.V.



# STS Guide Light

## STS Pre-Preparation System



#### SAFE AND ACCURATE PRE-FILLING

When processing half-tablets, rarely used medicines or specially shaped tablets, the automated dispensing system with LEDs allows for safe and accurate pre-filling, while reducing filling time and preventing filling or dispensing errors.



#### PRE-FILL CHECKING WITH LEDS

Individual LEDs for each cell help in dispensing the necessary tablets and indicate errors to ensure convenient and accurate filling.



#### FAST AND ACCURATE STS TABLET COLLECTION

The list of STS medicines transmitted from the server can be printed to enable fast and accurate medicine picking from storage.



/er. 220318

Model	JV-GL10*
Dimensions (WxDxH)	565,4 x 279 x 50,3mm
Weight	About 1,85kg
Power consumption	15W (Max. 25W)
Power supply	100-240V~, 50/60Hz
Operation Temperature	0~40°C
Operation Humidity	10 ~ 80%

\* Product exterior and specifications are subject to change due to the company's research and development results without any prior notice \*\* All information contained herein may not be duplicated, copied, altered, or quoted without the expression written consent of JVM.

